




*Shown with optional stand



DS-8500 Mounting Solution Guide

Configuration


DS-8500 Bedside Monitor Mounting



LC-8015TC - 15" Display Unit
LC-8019TC - 19" Display Unit




DSC-8530 - Main Unit



OAO-44A - Stand
 (optional)

Module Connection Cable

*Connect to Main Unit DSC-8530



- **CJO-08SS1.5** (1.5M)

Special Order Item

- **CJO-08SS0.3** (0.3M)
- **CJO-08SS3.5** (3.5M)
- **CJO-08SS5** (5M)




DSA-82
 DS-8007 Adapter



DS-8007M
 Masimo® Model

DS-8007N
 Nellcor™ Model



HSA-80
 HS- Adapter



HS-8312M
 Masimo® HS Module

HS-8312N
 Nellcor™ HS Module



IB-8004
 Input Box



HG-820
 Nellcor™
 SpO2 Module



HG-810
 Masimo®
 SpO2 Module



HM-800
 Multi-Module



HP-800
 Multi Port
 Module




HM-801
 Multi-Module

DS-8500 with No Additional Units (GCX® Mounting) Configuration



DS-8500
System

*optional OAO-44A Stand available



CJO-08SS1.5
Module Connection Cable



HS-8312N/M with **HSA-80**
HS Super Module HS Adapter

Mounting Parts



WMM-0006-04
Dual Utility Hook

OR



WS-0003-26A
Quad Utility Hook

Arm Options



FD-0027-01
Wall Mount
Fixed Arm

OR




FD-0027-02
Wall Mount
Variable Height

OR



FD-0033-01
Wall Mount
Variable Height



WMM-0006-11
Downpost (10")

*Single Stage Fixing
Post for Modules




FD-0027-83
Single-sided
Downpost-tray
Adapter



FD-0030-80
Mounting Tray
for HS-8312N/M


DS-8500 with EtCO2 Module (GCX® Mounting)

Configuration




DS-8500 System

*optional OAO-44A Stand available



CJO-08SS1.5
Module Connection Cable



CJO-15RR0.65G
AUX Connection Cable
*Use with OAO-59A Clamp Holder



HS-8312N/M
HS Super Module
with **HSA-80** HS Adapter



HCP-810
Sidestream Unit



HPD-810
Mainstream Unit

OR

Mounting Parts



WMM-0006-04
Dual Utility Hook


OR



WS-0003-26A
Quad Utility Hook



FD-0030-80
Mounting Tray
for HS-8312N/M



WMM-0006-11
Downpost (10")

*Single Stage Fixing Post for Modules



FD-0027-83
Single-sided
Downpost-tray
Adapter



OAO-59A
HPD/HCP
Clamp Holder
*Can be used without the clamp

OR



FD-0027-01
Wall Mount
Fixed Arm



FD-0027-02
Wall Mount
Variable Height

OR



FD-0033-01
Wall Mount
Variable Height


Arm Options

DS-8500 with Recorder & EtCO2 Module (GCX® Mounting) Configuration




DS-8500
System

*optional OAO-44A Stand available



CJO-09SS1.5
Unit Connection Cable
(U-LINK)



CJO-08SS1.5
Module Connection Cable
*Use with OAO-59A Clamp Holder



CJO-15RR0.65G
AUX Connection Cable



HR-800
3CH Thermal Printer



HS-8312N/M
HS Super Module
with **HSA-80** HS Adapter



HCP-810
Sidestream Unit

OR



HPD-810
Mainstream Unit

Mounting Parts




WMM-0006-04
Dual Utility
Hook

OR



WS-0003-26A
Quad Utility Hook



WMM-0006-11
Downpost (10")
*Single Stage Fixing
Post for Modules



FD-0027-01
Wall Mount
Fixed Arm

OR



FD-0027-02
Wall Mount
Variable Height

OR



FD-0028-80
Mounting Tray
for HR-800



FD-0030-80
Mounting Tray
for HS-8312N/M



FD-0027-84
Double-sided
Downpost-tray
Adapter



OAO-59A
HPD/HCP
Clamp Holder
*Can be used without
the clamp




FD-0033-01
Wall Mount
Variable Height

DS-8500 with IB-8004 Input Box Unit, Recorder & EtCO2 Module (GCX® Mounting) Configuration



DS-8500 System


*optional OAO-44A Stand available



CJO-09SS1.5 Unit Connection Cable (U-LINK)



HR-800 3CH Thermal Printer



CJO-08SS1.5 Module Connection Cable



IB-8004 Input Box



HS-8312N/M HS Super Module with HSA-80 HS Adapter



CJO-15RR0.65G AUX Connection Cable
*Use with OAO-59A Clamp Holder




HCP-810 Sidestream Unit

OR



HPD-810 Mainstream Unit

Mounting Parts




WMM-0006-12 Downpost (16")


*Dual Stage Fixing Post for Modules



FD-0028-80 Mounting Tray for HR-800



FD-0030-80 Mounting Tray for HS-8312N/M



FD-0031-80 Mounting Tray for IB-8004



FD-0027-01 Wall Mount Fixed Arm

OR



FD-0027-02 Wall Mount Variable Height

OR



FD-0027-83 Single-sided Downpost-tray Adapter



FD-0027-84 Double-sided Downpost-tray Adapter



OAO-59A HPD/HCP Clamp Holder
*Can be used without the clamp



WMM-0006-04 Dual Utility Hook

OR



WS-0003-26A Quad Utility Hook



FD-0033-01 Wall Mount Variable Height

Arm Options

DS-8500 with MGU-801 Gas Module

Confirm the following checklist when mounting on an Anesthesia Machine:

- Check the **Model Number** and **Vendor** of the Anesthesia Machine. Take a photo of the anesthesia machine if possible.
- Confirm customer's request.
(ie. if they want to mount on top of the anesthesia machine, or on the side of the machine, etc.)
- Whether the customer want the VHM arm or M series mount, if mounting on the side of the anesthesia machine.




DS-8500 with MGU-801 Gas Module and Recorder (GCX® Mounting) Configuration




DS-8500
System

*optional OAO-44A Stand available



CJO-08SS1.5
Module Connection Cable



CJO-09SS1.5
Unit Connection Cable (U-LINK)



HS-8312N/M
HS Super Module
with **HSA-80** HS Adapter



MGU-801P
AGO2 Gas Unit



HR-800
3CH Thermal Printer

Mounting Parts



WMM-0006-04
Dual Utility
Hook

OR



WS-0003-26A
Quad Utility
Hook



WMM-0006-12
Downpost (16")
*Dual Stage Fixing
Post for Modules



FD-0028-80
Mounting Tray
for HR-800



FD-0027-01
Wall Mount
Fixed Arm

OR



FD-0027-02
Wall Mount
Variable Height



FD-0030-80
Mounting Tray
for HS-8312N/M



FD-0032-80
Mounting Tray
for MGU-801P



FD-0027-83
Single-sided
Downpost-tray
Adapter



FD-0027-84
Double-sided
Downpost-tray
Adapter

OR



FD-0033-01
Wall Mount
Variable Height


DS-8500 with All Modules and Units (GCX® Mounting)

Configuration




DS-8500
System

*optional OAO-44A Stand available



CJO-08SS1.5
Module Connection Cable



CJO-09SS1.5
Unit Connection Cable (U-LINK)



HS-8312N/M
HS Super Module
with **HSA-80**
HS Adapter



IB-8004
Input Box



MGU-801P
AGO2 Gas Unit



HR-800
3CH Thermal Printer

Mounting Parts



WMM-0006-04
Dual Utility
Hook

OR



WS-0003-26A
Quad Utility
Hook



WMM-0006-12
Downpost (16")
*Dual Stage Fixing
Post for Modules



FD-0028-80
Mounting Tray
for HR-800



FD-0027-01
Wall Mount
Fixed Arm

OR



FD-0027-02
Wall Mount
Variable Height

OR



FD-0030-80
Mounting Tray
for HS-8312N/M



FD-0031-80
Mounting Tray
for IB-8004



FD-0032-80
Mounting Tray
for MGU-801P











FD-0027-84 x2
Double-sided
Downpost-tray
Adapter



FD-0033-01
Wall Mount
Variable Height

Arm Options

DS-8500 Module Configuration for Fukuda Mounting

							
HS-8312 Super Module	HCP-810/HPD-810 EtCO2	HBX-800 BISx	HR-800 Recorder	MGU-801P Gas Unit	IB-8004 Input Box	OAO-52A HS Fixing Base	MXD-M3-36617-01 Dual Base Mounting Tray
●	●					1	
●		●				1	
●			●			1	
●				●		1	
●					●	1	
●	●		●			2	1
●		●		●		2	1
●			●	●		2	1
●	●		●		●	3	1
●		●		●	●	3	1
●			●	●	●	3	1

DS-8500 with Up to 2 Modules (Fukuda Mounting)

MONITOR CONFIGURATION



DS-8500
System

*optional OAO-44A Stand available

MODULE CONFIGURATION



HS-8312N/M HS Super Module
with **HSA-80** HS Adapter

PICK ONE OTHER MODULE



HCP-810/HPD-810
EtCO2 Unit



HBX-800
BISx Module
Interface



HR-800
3CH Thermal
Printer



MGU-801P
AGO2
Gas Unit



IB-8004
Input Box



with **OAO-59A**
Holder



with **OAO-59A**
Holder

Arm Options



FD-0027-01
Wall Mount
Fixed Arm

OR




FD-0027-02
Wall Mount
Variable Height

OR




FD-0033-01
Wall Mount
Variable Height

Mounting Parts



OAO-52A
HS Fixing Base



FD-0020-16
Base Plate Adapter

Arm Option



WMM-0012-06
M Series Fixed Height
Arms (8 inch)



FD-0033-01
Wall Mount
Variable Height

DS-8500 with UP to 3 Modules (Fukuda Mounting)

MONITOR CONFIGURATION



DS-8500
System

*optional OAO-44A Stand available

MODULE CONFIGURATION



HS-8312N/M HS Super Module
with **HSA-80 HS Adapter**

PICK TWO OTHER MODULES



HCP-810/HPD-810
EtCO2 Unit

OR



HBX-800
BISx Module
Interface

OR



HR-800
3CH Thermal
Printer

OR



MGU-801P
AGO2
Gas Unit

OR



IB-8004
Input Box



with **OAO-59A**
Holder



with **OAO-59A**
Holder

Arm Options



FD-0027-01
Wall Mount
Fixed Arm

OR




FD-0027-02
Wall Mount
Variable Height

OR



FD-0033-01
Wall Mount
Variable Height

Mounting Parts



OAO-52A x 2
HS Fixing Base



MXD-M3-36617-01
Dual Base Mounting
Tray



FD-0020-16
Base Plate Adapter

Arm Option




WMM-0012-06
M Series Fixed Height
Arms (8 inch)



FD-0033-01
Wall Mount
Variable Height

Sample Pictures



*mounting solution differs for each configuration



FUKUDA DENSHI USA, INC.
 17725-C NE 65th Street Redmond, WA 98052
 Toll Free: (800) 365-6668 / Local: (425) 881-7737 / Fax: (425) 869-2018
 www.fukudaamerica.com

GCX® is a registered trademark of GCX Corporaon.
 The information contained in this document is subject to change
 without notice. © 2022 FUKUDA DENSHI USA, INC. All rights reserved.